

# RF4<sup>®</sup>

FOCUS DESIGN AND CONCEPT



## RF-ED4S

**ED4S说明书**

**ED4S Instruction Manual**

感谢购买使用我司该产品, 请务必仔细阅读并妥善保管本手册, 它将帮助你更好地使用该产品。

Thank you for purchasing this product, please read this manual carefully and keep it in a safe place, it will help you to use this product better.

## 一、设备参数

参数类型	参数值
工作电压	3.7V
工作电流	1A
充电电流	200mA
充电时间	2hr
转速	250rpm
转速档位数	4

## 二、包装清单

1. ED4S电动螺丝刀1个
2. 批头6组(42个)
3. TYPE-C电源线1根
4. 底座1个




## 三、使用准备

- 1.底座通过TYPE-C线进行供电
- 2.使用前将ED4S的批头接口方向对准底座,并插入充电(充电前需取出批头)  
演示图
- 3.将所需批头从底座中取出并插入ED4S的批头接口中



## 四、按键说明

- 1.正转按钮
- 2.反转按钮
- 3.档位切换按钮



## 五、客户使用注意事项

- 1.使用前请充电
- 2.请勿剧烈碰撞

# I .Equipment parameters

Parameter Types	Parameter Values
Working Voltage	3.7V
Working Current	1A
Charging Current	200mA
Charge Time	2hr
Rotation speed	250rpm
Number of RPM gears	4

## II .Packing list

- 1.ED4S
- 2.Screwdriver bits 6 sets (42 pcs)
- 3.1 TYPE-C cable
4. 1 Base




### III.Preparation for use

- 1.Base connects to power supply via TYPE-C cable
- 2.Before use, align the ED4S's screwdriver head interface with the base and plug it into the charging (remove the screwdriver head before charging)
- 3.Remove the desired screwdriver head from the base and insert it into the screwdriver head interface of the ED4S



### IV.Description of buttons

- 1.Forward button
- 2.Reverse button
- 3.Gear shift button



### V.Customer use precautions

1. Please charge before use
- 2.Please do not collide violently