



RF-P6

用户使用手册


USER MANUAL

感谢购买使用我司产品，务请仔细阅读并妥善保管本手册，它将帮助你更好地使用产品。
Thanks for using our products. Please read the manual carefully and it will be helpful for you to use this products better.


操作说明

- 长按“开关键”开启高速风扇1档，短按切换2档,3档,4档,5档关机依次循环，显示屏显示档位3秒后切换到当前电量。
- 双击“开关键”开启小夜灯照明，再次双击暴闪模式，再次双击关闭照明。
- 按住暴力风扇开关键开启暴力风扇，松开后关闭。

功能说明



- 1.开关
- 2.显示屏



- 3.Type-C充电口
- 4.暴力风扇开关键
- 5.小夜灯


产品参数

图片	最小工作功率	最高转速
	10W	200000r/min
	最大工作功率	最高风速
	65W	42m/s
	最大输入功率	LED功率
	5V 2A	1.5W
	充电功率	工作温度
	10W	0-40°C
	充电时长	马达直径
	3小时	28.8mm
工作档位		
一档、二档、三档、四档、五档、超频档,共6档		


Operating instructions

- Long press the "On key" to open the first gear of the high-speed fan, short press to switch the second gear, the third gear, the fourth gear, the fifth gear, the shutdown cycle in turn, and the display gear will switch to the current power after 3 seconds
- Double-click "On Key" to turn on the night light, double-click the flash mode again, and double-click again to turn off the lighting
- Press and hold the switch key of the violent fan to open the violent fan, release it and close it.

Function Description



1. On-off key
2. Display



3. Type-C charging port
4. Violent fan power button
5. Night Light

Product parameter

picture	Minimum working power	Maximum speed
	10W	200000r/min
	Maximum working power	Maximum wind speed
	65W	42m/s
	Maximum input power	LED power
	5V 2A	1.5W
	Charging power	Working temperature
	10W	0-40°C
	Charging time	Motor diameter
	3 hours	28.8mm
Work gears		
First gear, second gear, third gear, fourth gear, fifth gear, overlocking gear, a total of 6 gears		